Technical Paper Session 8 Contemporary Steam and Hot Water Design

Humidification Requirements in Economizer-Type HVAC Systems (DA-13-022)

Viktor T. Toth http://www.vttoth.com/ vttoth@vttoth.com

Learning Objectives

- Learn formulae that can be used, together with ASHRAEprovided climate data, to find the maximum humidification load in both temperature-based and enthalpy-based economizer systems.
- Understand how to better simulate the performance of whole-house tankless water heaters.
- Learn about a new boiler model for dynamic simulations that aims for easy parameterization.
- Assess the performance of portable disk humidifiers.

ASHRAE is a Registered Provider with The American Institute of Architects Continuing Education Systems. Credit earned on completion of this program will be reported to ASHRAE Records for AIA members. Certificates of Completion for non-AIA members are available on request.

This program is registered with the AIA/ASHRAE for continuing professional education. As such, it does not include content that may be deemed or construed to be an approval or endorsement by the AIA of any material of construction or any method or manner of handling, using, distributing, or dealing in any material or product. Questions related to specific materials, methods, and services will be addressed at the conclusion of this presentation.

Agenda for Session

 Learn formulae that can be used, together with ASHRAE-provided climate data, to find the maximum humidification load in both temperature-based and enthalpybased economizer systems.

The problem

- In an economizer type system, the ratio of outside air vs. return air varies as a function of outside conditions
- How do you calculate the loads, specifically the humidification load, as a function of outside conditions?

Fundamental equations

- Can be derived easily from first principles (statistical thermodynamics)
- Basic relationship between enthalpy (*h*) temperature (*T*) and humidity ratio (*w*) is given by

 $h = c_P T + h^{\operatorname{vap}} w,$

(c_P : specific heat at constant pressure, h^{vap} : latent heat of vaporization)

• NB: *c*_{*P*} can be derived from first principles

Enthalpy and temperature

- ASHRAE Handbook sets h = 0 at the start of the temperature scale (0°C or 0°F)
- This ignores the fact that the heat content of dry and moist air are not the same at that temperature
- Derivative of the equation that connects T, h, c_P and w reads:

$$\frac{\partial h}{\partial w} = T \frac{\partial c_P}{\partial w} + h^{\mathrm{vap}}$$

- This equation only makes sense if *T* represents absolute temperature
- For accurate results for processes that change the humidity content, enthalpy should be normalized such that *h* = 0 at absolute zero

Conservation laws

- The properties of air in an HVAC system can be calculated using conservation laws
- Conserved quantities are:
 - The mass of dry air
 - The mass of moisture
 - Energy (enthalpy)
- These quantities can only change in response to external influences (e.g., adding outside air, heating)

Mixing air

 Consider two quantities of air characterized by masses m₁ and m₂, humidity ratios w₁ and w₂, and enthalpies h₁ and h₂. When you mix them, conservation laws determine the values of m, w and h for the mixture:

$$\begin{split} m &= m_1 + m_2, \\ w &= \frac{w_1 m_1 + w_2 m_2}{m_1 + m_2}, \\ h &= \frac{h_1 m_1 + h_2 m_2}{m_1 + m_2}. \end{split}$$


Economizer systems

- Vary the ratio of outside vs. return air based on outside conditions:
 - Minimum outside air when it's hot, to reduce air conditioning costs;
 - 100% outside air when it's cool, to maximize the benefits of acceptable outside conditions;
 - Modulated outside air when it's very cold, to minimize heating costs.

Enthalpy-based systems

- Temperature-based system draws in outside air so long as it's colder
- Slightly colder but very humid outside air can result in increased A/C costs
- Problem is avoided if enthalpies are compared instead.

Economizer systems



Humidification in economizers

- Worst-case humidification is at the bottom end of the outside air conditions region in the psychrometric chart
- This may be to the left (OA modulated) or to the right (100% OA) of the minimum supply temperature requirement
- Mixed air state point is calculated accordingly



• Outside air quantity is given by:

$$m_{\mathrm{OA}} = \max\left(-\frac{\left[c_{P}^{\mathrm{wv}}w_{\mathrm{RA}} + c_{P}^{\mathrm{da}}\right]\left[T_{\mathrm{RA}}^{\star} - T_{\mathrm{MA}}^{\star}\right]}{\left[c_{P}^{\mathrm{wv}}w_{\mathrm{OA}} + c_{P}^{\mathrm{da}}\right]\left[T_{\mathrm{OA}}^{\star} - T_{\mathrm{MA}}^{\star}\right]}, \alpha\right)m_{\mathrm{RA}},$$

• Mixed air humidity ratio is given by:

$$w_{\rm MA} = \frac{w_{\rm OA}m_{\rm OA} + w_{\rm RA}m_{\rm RA}}{m_{\rm OA} + m_{\rm RA}}.$$

(MA: mixed air, OA: outside air, RA: return air, wv: water vapor, da: dry air, α: minimum outside air ratio)

Completing the calculation

- Once w_{MA} is known, humidification requirement is trivially calculated
- Calculation can be repeated for the lower edge of the outside conditions range
- Worst-case result can be used to load-size the system
- Similar approach can be used to calculate heating, cooling, dehumidification loads

Conclusions

- Enthalpy- or temperature based? Really doesn't matter for humidification as we are concerned about the lower edge of the outside air regime
- But, this analysis can also be used for other (e.g., cooling, dehumidification) processes
- For processes involving changes in humidity ratio, using the correct starting point for the enthalpy scale is critical

Questions?

Viktor T. Toth vttoth@vttoth.com

Bibliography

 Humidification requirements in economizer-type HVAC systems

ASHRAE Transactions 119(1) (pending publication).

Supporting slide for questions

• Outside air quantity is given by:

$$m_{\rm OA} = \begin{cases} -\frac{(c_P^{\rm wv} w_{\rm RA} + c_P^{\rm da})(T_{\rm RA}^{\star} - T_{\rm MA}^{\star})}{(c_P^{\rm wv} w_{\rm OA} + c_P^{\rm da})(T_{\rm OA}^{\star} - T_{\rm MA}^{\star})} m_{\rm RA} & \text{if } -\frac{(c_P^{\rm wv} w_{\rm RA} + c_P^{\rm da})(T_{\rm RA}^{\star} - T_{\rm MA}^{\star})}{(c_P^{\rm wv} w_{\rm OA} + c_P^{\rm da})(T_{\rm OA}^{\star} - T_{\rm MA}^{\star})} > \alpha, \\ & \alpha m_{\rm RA} & \text{if } -\frac{(c_P^{\rm wv} w_{\rm RA} + c_P^{\rm da})(T_{\rm RA}^{\star} - T_{\rm MA}^{\star})}{(c_P^{\rm wv} w_{\rm OA} + c_P^{\rm da})(T_{\rm OA}^{\star} - T_{\rm MA}^{\star})} \le \alpha. \end{cases}$$

Mixed air humidity ratio is given by:

$$w_{\rm MA} = \begin{cases} \frac{w_{\rm OA}m_{\rm OA} + w_{\rm RA}m_{\rm RA}}{m_{\rm OA} + m_{\rm RA}} & \text{if } -\frac{(c_P^{\rm wv}w_{\rm RA} + c_P^{\rm da})(T_{\rm RA}^{\star} - T_{\rm MA}^{\star})}{(c_P^{\rm wv}w_{\rm OA} + c_P^{\rm da})(T_{\rm OA}^{\star} - T_{\rm MA}^{\star})} > \alpha, \\ \frac{\alpha w_{\rm OA} + w_{\rm RA}}{1 + \alpha} & \text{if } -\frac{(c_P^{\rm wv}w_{\rm RA} + c_P^{\rm da})(T_{\rm RA}^{\star} - T_{\rm MA}^{\star})}{(c_P^{\rm wv}w_{\rm OA} + c_P^{\rm da})(T_{\rm OA}^{\star} - T_{\rm MA}^{\star})} \le \alpha, \end{cases}$$

(MA: mixed air, OA: outside air, RA: return air, wv: water vapor, da: dry air, α: minimum outside air ratio)